

Advanced Radio Functions

Your radio includes several advanced features that can be activated using the channel up/down keys. These functions are triggered with a long press, which means holding the button(s) for more than two seconds.

Channel Lock

The **Channel Lock** feature prevents accidental changes to your selected channel.

- To **activate Channel Lock**, press and hold **both the UP and DOWN buttons** together for more than two seconds. (You will hear a single “beep”, indicating that the channel lock is active)
- To **deactivate Channel Lock**, repeat the same action. (A double “beep” will confirm that the channel is unlocked)

Monitor Function

The **Monitor Function** temporarily disables the **squelch**, a feature that blocks background static or weak signals when no transmission is detected.

- To **enable monitoring**, press and hold the **UP (+) key**.
 - This will allow you to hear all signals, including weak ones that wouldn't normally pass the squelch filter.
- To **disable monitoring**, release the button.



Revision #2

Created 2026-05-27 21:20:09 UTC by Alan Scott

Updated 2026-05-27 21:40:03 UTC by Alan Scott